

Assembly and maintenance manual

Type RSCI20-RSCI130



Hatschekstr.36
69126 Heidelberg
Germany
Phone +49(0)6221 30470
Fax +49(0)6221 304731
info@stieber.de
www.stieber.de

Issue date: 25.03.2014 GB
Revision:2 /31/07/2023/ GB

U:\EngUsers\ProduktDoku\1AAA_Einbauerklaerung_Wartungsanleitung_Konformitaetserklaerung\1AAA_Wartungsanleitungen\Original_Worddatei\M1022E_2_RSCI20-RSCI130.docx

General safety instructions

	WARNING!	Risk of injury due to moving components! Rotating driven components can cause the most severe injuries. Therefore, during operation: ➤ It is strictly forbidden for persons to loiter in the danger zone or in its immediate vicinity. ➤ Do not disable, render unusable or circumvent safety equipment and / or safety functions. Prior to entering the danger zone: ➤ Switch off the power supply and secure it against being switched on again. ➤ Wait for lagging components to come to a standstill.
	DANGER!	Danger due to improper operation! ➤ Modifications to the one-way clutch are not permitted and may impair safety. ➤ All tasks may only be performed by personnel with the requisite training and expertise. ➤ Repairs and maintenance tasks may only be performed when the machine is at a standstill. To this end, the machine is to be secured against a restart.
	WARNING!	Risk of injury due to incorrect assembly! Faulty installation and maintenance can cause severe property damage and personal injury. Installation, maintenance and repair work may only be performed by personnel with the requisite training and expertise.
	WARNING!	Risk of injury for insufficiently qualified personnel! Improper handling can cause significant personal injury and property damage. Therefore: Only ever have tasks performed by those persons to whom the tasks have been assigned.

Table of contents

	Page
General safety instructions	2
1 General	4
1.1 Information relating to the assembly and maintenance manual	4
1.2 Explanation of symbols	4

1.3	Manufacturer	5
1.4	Labeling	5
1.5	Environmental protection	5
2	Safety	5
2.1	Intended use	5
2.2	Responsibility of the operator	6
2.3	Assembly and maintenance personnel	6
2.4	Personal protective equipment	7
2.5	Limitations of use	7
3	Structure and function	9
3.1	Structure	9
3.2	Function	10
4	Transport and packaging	11
5	Storage	11
5.1	Short-term storage	11
5.2	Long-term storage	12
6	Installation	12
6.1	Checking the direction of rotation	12
6.2	Lubrication	14
6.2.1	Operation with oil lubrication	14
6.2.2	Operation with grease lubrication	14
6.3	Assembly	15
6.4	Mounting example	17
7	Maintenance	17
7.1	Disassembly in case of maintenance	18
7.2	Test criteria in case of maintenance	18
7.3	Assembly in case of maintenance when using grease lubrication	19
7.4	Assembly in case of maintenance when using oil lubrication	20
8	Disassembly	21
9	Disposal	22
10	Faults	23
11	Spare parts	23
12	Appendix	23
12.1	Layout drawing RSCI20-RSCI130	Fehler! Textmarke nicht definiert.

1 General

1.1 Information relating to the assembly and maintenance manual

This assembly and maintenance manual provides important information regarding the installation and commissioning of the one-way clutch.

Prerequisite for safe operation is compliance with all of the stated safety and handling instructions.

Moreover, the relevant local accident protection guidelines and general safety provisions for the field of application of the one-way clutch are to be complied with.

Read the assembly and maintenance manual carefully prior to installation and commissioning. It is a product component and must be kept in the immediate vicinity of the installation site and be accessible to personnel at all times. Furthermore, all safety instructions stated in the assembly and maintenance manual are to be observed.

1.2 Explanation of symbols

Warnings are marked throughout this assembly and maintenance manual by symbols. These warning symbols are introduced by signal words which indicate the extent of the danger. Comply with these warning symbols under all circumstances and act with due care and attention to avoid accidents, personal injury and property damage.

	DANGER!	...indicates an imminently dangerous situation which can be fatal or cause severe injuries if it is not averted.
	WARNING	...indicates a potentially dangerous situation which can be fatal or cause severe injuries if it is not averted.
	ATTENTION	...indicates a potentially dangerous situation which can cause minor or light injuries if it is not averted.
	CAUTION	...indicates a potentially dangerous situation which can cause property damage if it is not averted.
	NOTE	... highlights helpful tips and recommendations as well as information for efficient and fault-free operation.

1.3 Manufacturer

STIEBER GmbH, D-69126 Heidelberg, Hatschekstr. 36, Germany
Phone +49 (0) 6221 3047-0, Fax -31

1.4 Labeling

Front face of the outer race

- Manufacturer's name
- Type designation
- Date of manufacture (coded)

1.5 Environmental protection

Energy: The one-way clutch does not use any electrical energy

Materials: Steel

Recycling: Steel parts are up to 100% recyclable

2 Safety

2.1 Intended use

One-way clutches of type RSCI20-RSCI130 are directional clutches, engaged and disengaged automatically, depending on the relative direction of rotation.

The torque is transmitted by a force-locking connection. They can be used as overrunning clutches or backstops in machinery and equipment.

Driving operation of an overrunning clutch:

When operating in torque transmission mode the driving machine element and the driven member are connected in a force-locking manner. In this operating state, a torque will be transferred.

Overrunning operation of an overrunning clutch:

The overrunning clutch disengages automatically when the driven member rotates faster than the driving member.

The contact-free operation will be ensured, when the driven member connected with the inner race runs above a defined speed. From this speed up the wear-free operation of all function-relevant components is guaranteed.

Lockout mode of a one-way clutch:

When operating in the locking direction of the one-way clutch, the machine shaft and the torque bracing to the machine element are connected in a force-locking manner.

In this operating state, a torque will be transferred.

Overrunning mode of a one-way clutch:

The one-way clutch disengages automatically the force-locked connection between the machine shaft and the torque bracing to the machine element, when the machine shaft runs in freewheeling direction. The contact-free operation will be ensured, when the machine shaft is rotating above a defined speed. From this speed up the wear-free operation of all function-relevant components is guaranteed.

2.2 Responsibility of the operator

The operator of the machine, in which the one-way clutch is installed, is subject to the legal obligations concerning occupational safety.

The valid provisions for the site of operation as well as the safety and accident prevention regulations of the trade associations are to be observed. This, in particular, means that the operator:

- is aware of the valid occupational safety provisions.
- implements the necessary behavioral requirements for operation of the machine, in which the one-way clutch is installed, at the site of operation.
- clearly defines responsibilities for installation, operation, maintenance and cleaning of the machine in which the one-way clutch is installed.
- ensures that all staff members, who work at or with the machine in which the one-way clutch is installed, are employed and have read and understood the operating manual. Moreover, he must, at regular intervals, provide training for personnel on how to handle the machine, in which the one-way clutch is installed, and inform them of the potential dangers. In addition, the operator is responsible for ensuring that the machine in which the one-way clutch is installed:
 - is always in perfect technical condition.
 - is maintained in accordance with the specified maintenance intervals.
 - has all its safety equipment checked regularly for completeness and functionality.

2.3 Assembly and maintenance personnel

	WARNING	Risk of injury for insufficiently qualified personnel! Improper handling can cause significant personal injury and property damage. Therefore: ➤ Only ever have tasks performed by those persons to whom the tasks have been assigned.
---	----------------	--

Qualified personnel are those persons who, owing to their training, experience and instruction as well as their knowledge of relevant standards, provisions, accident prevention regulations and operating conditions, have been authorized by the person responsible for the safety of the plant to perform the requisite tasks and are able to recognize and avoid potential dangers in doing so. Knowledge of first-aid measures and on-site emergency equipment must also be included.

2.4 Personal protective equipment

It is necessary to wear personal protective equipment when handling the machine, in which the one-way clutch is installed, to minimize health risks.

The necessary protective equipment such as work shoes, gloves, safety goggles etc. is to be put on prior to all tasks and kept on during the task.

2.5 Limitations of use

Type RSCI	maximum bore dia. [mm]	maximum torque [Nm] *	Overrunning speeds [rpm]		maximum allowable torque trans- mission speed [rpm]	admissible runout (T.I.R.) outer race to shaft [mm]	admissible axial run-out outer race to shaft [mm]	Number/ size fixing screws
			min.	max.				
20	20	424	750	15000	315	0,3	0,10	6 x M6
20V	20	424	1000	15000	420	0,3	0,10	6 x M6
25	25	638	725	14000	300	0,3	0,10	6 x M6
25V	25	638	965	14000	405	0,3	0,10	6 x M6
30	30	750	700	11000	290	0,3	0,10	6 x M6
30V	30	750	925	11000	385	0,3	0,10	6 x M6
35	35	1100	670	11000	280	0,3	0,10	8 x M6
35V	35	1100	900	11000	375	0,3	0,10	8 x M6
40	40	1600	630	8000	260	0,3	0,10	8 x M8
40V	40	1600	830	8000	345	0,3	0,10	8 x M8
45	45	1824	610	7000	255	0,3	0,10	8 x M8
45V	45	1824	815	7000	340	0,3	0,10	8 x M8
50	50	2800	560	6000	235	0,3	0,10	8 x M8
50V	50	2800	740	6000	310	0,3	0,10	8 x M8
60	60	4700	510	6000	210	0,4	0,15	8 x M10
60S	60	4700	320	6000	130	0,4	0,15	8 x M10
60V	60	4700	640	6000	265	0,4	0,15	8 x M10
60VV	60	4700	820	6000	340	0,4	0,15	8 x M10
70	70	6100	470	4000	195	0,4	0,15	12 x M10
70S	70	6100	290	4000	120	0,4	0,15	12 x M10
70V	70	6100	610	4000	255	0,4	0,15	12 x M10
70VV	70	6100	780	4000	325	0,4	0,15	12 x M10
80	80	9000	440	4000	180	0,4	0,15	12 x M10
80S	80	9000	280	4000	115	0,4	0,15	12 x M10
80V	80	9000	560	4000	235	0,4	0,15	12 x M10
80VV	80	9000	720	4000	300	0,4	0,15	12 x M10
80M	80	11600	375	4000	155	0,4	0,15	12 x M10
80MS	80	11600	230	4000	95	0,4	0,15	12 x M10

Type RSCI	maximum bore dia. [mm]	maximum torque [Nm] *	Overrunning speeds [rpm]		maximum allowable torque trans- mission speed [rpm]	admissible runout (T.I.R.) outer race to shaft [mm]	admissible axial run-out outer race to shaft [mm]	Number/ size fixing screws
			min.	max.				
80MV	80	11600	480	4000	200	0,4	0,15	12 x M10
80MVV	80	11600	610	4000	255	0,4	0,15	12 x M10
90	90	11200	410	3000	170	0,4	0,15	12 x M12
90S	90	11200	255	3000	105	0,4	0,15	12 x M12
90V	90	11200	520	3000	215	0,4	0,15	12 x M12
90VV	90	11200	670	3000	280	0,4	0,15	12 x M12
90M	90	17400	350	3000	145	0,4	0,15	12 x M12
90MS	90	17400	285	3000	120	0,4	0,15	12 x M12
90MV	90	17400	445	3000	185	0,4	0,15	12 x M12
90MVV	90	17400	570	3000	235	0,4	0,15	12 x M12
100	100	21000	355	3000	145	0,6	0,20	12 x M16
100S	100	21000	215	3000	90	0,6	0,20	12 x M16
100V	100	21000	520	3000	215	0,6	0,20	12 x M16
100VV	100	21000	670	3000	280	0,6	0,20	12 x M16
100M	100	32000	340	2400	140	0,4	0,1501	12 x M16
100MS	100	32000	220	2400	90	0,4	0,1501	12 x M16
130	130	31500	330	2400	135	0,6	0,20	12 x M16
130S	130	31500	195	2400	80	0,6	0,20	12 x M16
130V	130	31500	480	2400	200	0,6	0,20	12 x M16
130VV	130	31500	565	2400	235	0,6	0,20	12 x M16
130M	130	42000	320	2400	130	0,4	0,15	12 x M16

S: cage design with weaker spring

V: cage design with reinforced spring

VV: cage design with double-reinforced spring




NOTE

With smaller bore diameters than the maximum bore diameter, the maximum transmittable torque depends on the keyway connection (see DOKU-drawing)!

- Limits for ambient temperature: from –20°C to +80°C
- Maximum operating temperature: 90°C
- Overrunning: Machine shaft (inner race)
- Required machine shaft tolerance: d = h6 or j6
- Required tolerance outer race centering (inner diameter) :
d = H6 or G6
- Oil lubrication: approved oils according Stieber catalogue / WN900
- Grease lubrication: approved greases according Stieber catalogue / WN900

3 Structure and function

3.1 Structure



- | | |
|--------|------------|
| Pos. 1 | Outer race |
| Pos. 2 | Inner race |
| Pos. 3 | Circlip |
| Pos. 8 | Cage |

Fig. 1 Structure

3.2 Function

When the torque is transmitted through the one-way clutch, the outer race (1) and the inner race (2) are coupled in a force-locked manner (see Fig. 2). For this purpose, clamping elements are used, the outer contours of which generates the force-locked coupling. The clamping elements are integrated into a cage (8) and are energized by springs into contact with the outer and inner race. The springs ensure rapid responding behavior of the one-way clutch at the start of torque transmission.




Fig.2 Torque transmission

In overrun operation, above the minimum permissible overrunning speed, the centrifugal force, in connection with the geometry of the clamping elements, generates a force which turns the clamping elements against the spring force (see Fig. 3). A contact-free position is brought about in this way so that wear-free operation of the one-way clutch can be achieved. The minimum permissible overrunning speed may only be lower for a short period during the start-up or shut-down stage otherwise the damage to the contact partner caused by wear and tear may lead to the failure of the one-way clutch.




Fig.3 Contact-free position

4 Transport and packaging



NOTE

The local provisions regarding the disposal of transport and packaging materials are to be observed.

One-way clutches of Type RSCI20-RSCI130 are packaged in non-absorbent corrosion protection paper. All components are sent in a box.

To prevent the component from breaking or falling apart they are secured by a transportation lock (see Figure 4) from size RSCI90.

Up to size RSCI80 the one-way clutches are fixed with a cable clip.

Transport damage to the packaging and / or the one-way clutch is to be reported to the respective transit company!

The one-way clutch must be unpacked in a clean and dry environment!




Fig. 4 Transportation lock

5 Storage

5.1 Short-term storage

One-way clutches of Type RSCI20-RSCI130 come with an oil film as corrosion protection. This corrosion protection is to be renewed at regular intervals. The frequency of these renewal intervals is dependent on the environmental conditions (temperature, moisture, salt content of the air, etc.) at the storage site.

The maximum storage period (short-term storage) is 6 months. Moreover, the one-way clutch must have long-term storage corrosion protection applied to it.

Store packages under the following conditions:

- Do not keep outdoors.
- Keep dry and free from dust.
- Do not expose to aggressive media.
- Keep away from direct sunlight.
- Avoid mechanical shocks and vibrations.
- Storage temperature: -10 to +60 °C.
- Relative humidity: maximum 95%, non-condensing.

5.2 Long-term storage

To this end the one-way clutch must be welded in PE foil with desiccant agent. The corrosion protection must be checked after a period not exceeding one year or else depending on the environmental conditions (temperature, moisture, salt content of the air, etc.) at the storage site.

Store packages under the following conditions:

- Do not keep outdoors.
- Keep dry and free from dust.
- Do not expose to aggressive media.
- Keep away from direct sunlight.
- Avoid mechanical shocks and vibrations.
- Storage temperature: -10 to +60 °C.
- Relative humidity: maximum 95%, non-condensing.

6 Installation

6.1 Checking the direction of rotation

	WARNING	Risk of injury due to moving components! Rotating driven components can cause the most severe injuries. Therefore, during operation: ➤ It is strictly forbidden for persons to loiter in the danger zone or in its immediate vicinity. ➤ Do not disable, render unusable or circumvent safety equipment and / or safety functions. Prior to entering the danger zone: ➤ Switch off the power supply and secure it against being switched on again. ➤ Wait for lagging components to come to a standstill.
---	----------------	--

	WARNING	Risk of injury due to incorrect assembly! Faulty installation and maintenance can cause severe property damage and personal injury. Installation, maintenance and repair work may only be performed by personnel with the requisite training and expertise.
	CAUTION	Risk of injury due to falling components! The outer race or inner race can fall down if the transportation lock has been removed. Fasten the outer / inner race axially.

The direction of rotation at idle speed is marked as FREE on the cage (8). The direction of rotation can be changed by turning the inner race (2) including cage (8).

Procedural steps:

- Place the one-way clutch facing upward the label "FREE" on an assembly table
- Remove the transportation lock.
- Lift the inner race (2) including the cage (8) out of the outer race (1). Use appropriate lifting gear at the threaded hole of the inner race for this.
- Place the inner race (2) including the cage (8) facing downwards the label "FREE" on an assembly table.
- Secure (see Fig. 5 and 6) the clamp bodies in lift-off position (against the spring force) using an O-ring / cable connector as an assembly aid.




Figure 5: Clamp bodies "neutral position"




Figure 6: Clamp bodies "after lift-off"

- Insert the inner race (2) with cage (8) into the outer race (1) until half of the clamp body is covered.

	NOTE	The assembly aid (O-ring / cable connector) must be completely removed. Non-observance of this note can cause functional impairment and even failure.
---	-------------	---

- Remove the assembly aid (O-ring / cable connector) completely and lower the inner race and cage completely.
- Check overrunning. The one-way clutch must be able to be turned easily in the overrun direction of rotation.
- Install the transportation lock.

6.2 Lubrication

One-way clutches of Type RSCI20-RSCI130 do not require any lubrication in overrun operation above the lift-off speed as they operate without contact.

Similarly, no lubrication is required in lockout operation as only a minimal degree of rolling motion in the clamp bodies occurs.

Additional lubrication is required if the one-way clutch runs with frequently repeated or permanent working cycles below the lift-off speed. To this end, a lubricating film, which coats the clamp bodies and tracks of the outer race, is mandatory. The lifetime is limited under these operating conditions!

6.2.1 Operation with oil lubrication

An oil mist is sufficient for mounting inside a gear box.

If the one-way clutch runs with frequently repeated or permanent working cycles below the lift-off speed, splash lubrication or oil supply between the cage and the outer track is necessary. The lifetime is limited under these operating conditions!

The oil volume which is necessary for splash lubrication depends on the surrounding construction.

The level should be up to a maximum of 10 mm to an inside diameter of the outer race.

6.2.2 Operation with grease lubrication



NOTE

Excessive lubrication may negatively affect the one-way clutch functionality! Note the required grease quantities!



NOTE

Unsuitable lubricants can negatively affect the one-way clutch functionality! Only use greases approved by Stieber!

Select only lubricating greases complying with product catalogue/ Stieber WN900.

Procedural steps for greasing:

- Place the one-way clutch facing upward the label "FREE" on an assembly table.
- Remove the transportation lock.

- Lift the inner race (2) including the cage (8) out of the outer race (1). Use appropriate lifting gear at the threaded hole of the inner race for this.
- Grease the outer track with a layer thickness of approx. 1 mm:
 - Use grease of NLGI class 000 to 2 with a maximum base oil viscosity of 42 mm²/s
- Secure (see Fig. 5 and 6) the clamp bodies in lift-off position (against the spring force) using an O-ring / cable connector as an assembly aid.
- Insert the inner race (2) with cage (8) into the outer race (1) until half of the clamp body is covered.

**NOTE**

The assembly aid (O-ring / cable connector) must be completely removed. Non-observance of this note can cause functional impairment and even failure.

- Remove the assembly aid (O-ring / cable connector) completely and lower the inner race and cage completely.
- Check overrunning. The one-way clutch must be able to be turned easily in the overrun direction of rotation.
- Install the transportation lock.

6.3 Assembly

**WARNING****Risk of injury due to incorrect assembly!**

Faulty installation and maintenance can cause severe property damage and personal injury.
 Installation, maintenance and repair work may only be performed by personnel with the requisite training and expertise.

**WARNING****Risk of injury due to moving components!**

Rotating driven components can cause the most severe injuries.
 Therefore, during operation:

- It is strictly forbidden for persons to loiter in the danger zone or in its immediate vicinity.
- Do not disable, render unusable or circumvent safety equipment and / or safety functions.

Prior to entering the danger zone:

- Switch off the power supply and secure it against being switched on again.
- Wait for lagging components to come to a standstill.

**CAUTION****Risk of injury due to falling components!**

The outer race or inner race can fall down if the transportation lock has been removed.
 Fasten the outer / inner race axially.

Procedural steps :

- Lift up the one-way clutch using suitable lifting gear and push it onto the oiled machine shaft.
- Remove the transportation lock.
- Fasten the one-way clutch axially on the machine shaft.
- Center the outer race in the torque-supporting machine element.

**NOTE**

Screw qualities 12.9 must not be used!

- Secure the outer race in the torque-supporting machine element with the appropriate fixing screws (e.g. as per standard DIN EN ISO 4762) and with screw quality 10.9 or 8.8; tightening torque (see Table Tightening torque).

Tightening torque [Nm]		
Size	8.8	10.9
M6	11.3	16.5
M8	27.3	40.1
M10	54.0	79.0
M12	93.0	137.0
M16	230.0	338.0

Table: Tightening torque (according VDI 2230 Sheet1, $\mu=0.12$ metric standard thread)

- Check overrunning. The one-way clutch must be able to be turned easily in the overrun direction of rotation.

6.4 Mounting example




Figure 7: Mounting at the end of the shaft

7 Maintenance



WARNING

Risk of injury due to moving components!

Rotating driven components can cause the most severe injuries.

Therefore, during operation:

- It is strictly forbidden for persons to loiter in the danger zone or in its immediate vicinity.
- Do not disable, render unusable or circumvent safety equipment and / or safety functions.

Prior to entering the danger zone:

- Switch off the power supply and secure it against being switched on again.
- Wait for lagging components to come to a standstill.

	WARNING	Risk of injury due to incorrect assembly! Faulty installation and maintenance can cause severe property damage and personal injury. Installation, maintenance and repair work may only be performed by personnel with the requisite training and expertise.
---	----------------	--

	CAUTION	Risk of injury due to falling components! The outer race or inner race can fall down if the transportation lock has been removed. Fasten the outer / inner race axially.
---	----------------	---

One-way clutches of Type RSCI20-RSCI130 must be checked for damage and serviced after an operating period not exceeding 5 years.

7.1 Disassembly in case of maintenance

Procedural steps:

- Loosen the fastening screws of the outer race (1).
- Remove the axial retention of the inner race (2).

	CAUTION	Risk of injury due to falling components! The outer race or inner race can fall down if the transportation lock has been removed. Therefore: ➤ In certain cases install the transportation lock!
---	----------------	--

- Pull the one-way clutch from the machine shaft. Use suitable lifting gear for this.
- Place the one-way clutch facing upward the label "FREE" on an assembly table.
- In certain cases remove the transportation lock.
- Lift the inner race (2) including the cage (8) out of the outer race (1). Use appropriate lifting gear at the pull holes of the inner race for this.
- Remove the circlip (3) of the inner race (2) and pull the cage (8) off the inner race (2).

7.2 Test criteria in case of maintenance

Procedural steps:

- Pre-clean the outer race (1), inner race and cage (8) with a petroleum-based industrial cleaning agent and degrease with an acetone-based cleaning agent.
- Check for damage, wear and cracks (see the testing criteria):
 - The outer race track must not exhibit any signs of damage / ruptures

- Increased diameter due to wear in the outer race track maximum 0,05 mm compared to the area free from wear
- Traces of deformation / indentations to the track diameters of the inner and outer race maximum 0,05 mm deep
- Completeness of all spring elements (2 per clamp body)
- Spring elements free of damage / deformation
- Smooth rotation of the clamp bodies from stop to stop
- Maximum width of the wear facet on the clamp bodies (see Figure 8)




Figure 8: wear zones

- The one-way clutch can continue to be used only if all of the test criteria are met

7.3 Assembly in case of maintenance when using grease lubrication

Procedural steps:

- Mount the cage (8) on the inner race (2) and secure it axially using circlips (3).
- Grease the outer track with a layer thickness of approx. 1 mm:
 - Use grease of NLGI class 000 to 2 with a maximum base oil viscosity of 42 mm²/s
- Secure (see Fig. 5 and 6) the clamp bodies in lift-off position (against the spring force) using an O-ring / cable connector as an assembly aid.
- Insert the inner race (2) with cage (8) into the outer race (1) until half of the clamp body is covered.
- Remove the assembly aid (O-ring / cable connector) completely and lower the inner race and cage completely.



NOTE

The assembly aid (O-ring / cable connector) must be completely removed. Non-observance of this note can cause functional impairment and even failure.

- In certain cases install the transportation lock.
- Lift up the one-way clutch using suitable lifting gear and push it onto the oiled machine shaft observing the overrun direction of rotation in the process.
- In certain cases remove the transportation lock.
- Fasten the one-way clutch axially on the machine shaft.
- Center the outer race in the torque-supporting machine element.

**NOTE**

Screw qualities 12.9 must not be used!

- Secure the outer race in the torque-supporting machine element with the appropriate fixing screws (e.g. as per standard DIN EN ISO 4762) and with screw quality 10.9 or 8.8; tightening torque (see Table Tightening torque).

Tightening torque[Nm]		
Size	8.8	10.9
M6	11.3	16.5
M8	27.3	40.1
M10	54.0	79.0
M12	93.0	137.0
M16	230.0	338.0

Table: Tightening torque (according VDI 2230 Sheet1, $\mu=0.12$ metric standard thread)

- Check overrunning. The one-way clutch must be able to be turned easily in the overrun direction of rotation.

7.4 Assembly in case of maintenance when using oil lubrication

Procedural steps:

- Mount the cage (8) on the inner race (2) and secure it axially using circlips (3).
- Secure (see Fig. 5 and 6) the clamp bodies in lift-off position (against the spring force) using an O-ring / cable connector as an assembly aid.
- Insert the inner race (2) with cage (8) into the outer race (1) until half of the clamp body is covered.
- Remove the assembly aid (O-ring / cable connector) completely and lower the inner race and cage completely.

**NOTE**

The assembly aid (O-ring / cable connector) must be completely removed. Non-observance of this note can cause functional impairment and even failure.

- In certain cases install the transportation lock.

- Lift up the one-way clutch using suitable lifting gear and push it onto the oiled machine shaft observing the overrun direction of rotation in the process.
- In certain cases remove the transportation lock.
- Fasten the one-way clutch axially on the machine shaft.
- Center the outer race in the torque-supporting machine element.

**NOTE**

Screw qualities 12.9 must not be used!

- Secure the outer race in the torque-supporting machine element with the appropriate fixing screws (e.g. as per standard DIN EN ISO 4762) and with screw quality 10.9 or 8.8; tightening torque (see Table Tightening torque).

Tightening torque[Nm]		
Size	8.8	10.9
M6	11.3	16.5
M8	27.3	40.1
M10	54.0	79.0
M12	93.0	137.0
M16	230.0	338.0

Table: Tightening torque (according VDI 2230 Sheet1, $\mu=0.12$ metric standard thread)

- Check overrunning. The one-way clutch must be able to be turned easily in the overrun direction of rotation.

8 Disassembly

**WARNING****Risk of injury due to incorrect assembly!**

Faulty installation and maintenance can cause severe property damage and personal injury.

Installation, maintenance and repair work may only be performed by personnel with the requisite training and expertise.

	WARNING	Risk of injury due to moving components! Rotating driven components can cause the most severe injuries. Therefore, during operation: ➤ It is strictly forbidden for persons to loiter in the danger zone or in its immediate vicinity. ➤ Do not disable, render unusable or circumvent safety equipment and / or safety functions. Prior to entering the danger zone: ➤ Switch off the power supply and secure it against being switched on again. ➤ Wait for lagging components to come to a standstill.
---	----------------	--

	CAUTION	Risk of injury due to falling components! The outer race or inner race can fall down if the transportation lock has been removed. Fasten the outer / inner race axially.
---	----------------	--

Procedural steps:

- Loosen the fastening screws of the outer race (1).
- Remove the axial retention of the inner race (2).

	CAUTION	Risk of injury due to falling components! The outer race or inner race can fall down if the transportation lock has been removed. Therefore: ➤ In certain cases install the transportation lock!
---	----------------	---

- Pull the one-way clutch from the machine shaft. Use suitable lifting gear for this

9 Disposal

	NOTE	The local provisions regarding the disposal of metallic components and any lubricants present are to be observed.
---	-------------	--

The one-way clutch is comprised of metallic materials which are coated with grease or oil. Metallic materials are fully recyclable. Lubricants and anticorrosive agents are to be disposed of separately. The local disposal provisions are to be observed in this regard.

10 Faults

The manufacturer is to be contacted immediately should any faults arise.

STIEBER GMBH, D-69126 Heidelberg, Hatschekstr. 36, Germany
Tel +49 (0) 6221 3047-0, Fax -31

11 Spare parts



WARNING

Risk of injury due to incorrect spare parts!

Incorrect or faulty spare parts can cause damage, malfunctions or total failure as well as impair safety. Therefore:

- Only use original spare parts from the manufacturer.

Procure spare parts only from authorized dealers or from the manufacturer directly.

12 Appendix

12.1 Layout drawing RSCI20-RSCI130

