## *FF SVENDBORG BRAKES*



# HYDRAULIC POWER UNIT 2-STAGE BRAKING




### WHERE TO USE

The 2-stage hydraulic power unit provide a 2-stage controlled braking sequence for use with hydraulic fail-safe spring applied disc brakes. The 2-stage braking sequence is used to prevent a hard braking sequence, which in worst case can cause too high stress on the mechanical parts, or unwanted wear of the system through uncontrolled braking.

### **BRAKING PERFORMANCE**

During opening of the brakes the pressure is build up and thereby opening the brake(s). The first stage of the braking sequence is dumping the pressure to the correct pressure and after the 2-stage braking time the pressure is smoothly reduced and thereby increasing the braking torque.



### **FUNCTIONAL DESCRIPTION**

#### **Operation (Not Braking)**

Electrical power is connected to the electrical motor and the solenoid valve(s) is/are energized. The braking valve(s) is/ are closed and block the connection to tank. The hydraulic pressure is built up and disengages the brake and charges the accumulator.

The electrical power is disconnected from the motor by means of the motor pressure switch. The braking valve(s) is/are constantly energized. If the pressure is decreasing to the lower set point for motor pressure switch the motor will restart and increase the pressure again.

### Applying the Brake with Controlled Braking Torque

The electrical power is disconnected to the braking valve(s) and motor. The hydraulic oil pressure is released to the tank through the counter pressure valve(s) and the throttle valve(s), resulting in a constant reduced braking torque (MT%).

The reduced braking time is set by the flow control valve by bleeding the oil from the accumulator slowly through the flow control valve, maintaining a constant pressure in the brakes. When the accumulator is fully discharged the pressure in the brake will go to zero, and full braking torque is applied.

The constant brake torque and braking time is pre-set from factory as specified or if not specified set to 50% (MT%) of maximum torque and approximately 10sec stopping time ( $\Delta$ t).

#### **Operation in Case of Power Failure**

In case of power failure the brakes will be applied as described in the section: Applying the brake with controlled braking torque.



### **FEATURES**

The hydraulic power unit is available in two versions; a basic (single dump) and a premium (dual dump) with cabinet / enclosure with various options and accessories. The junction box / terminal box is mounted internally in the upper left hand side. Cable entry is in left hand side with removable entry plate in brass. The cabinet door is hinged either left hand or right hand side. The pressure connection / bulkhead (JIC as standard / Ermeto fitting 10L as optional) is mounted in left hand side but can be mounted in the right hand side or in the bottom as well.

2-Stage Braking Special Features

- Single return line / dump (Basic) or Dual return lines / dump for redundancy (Premium)
- Counter pressure valve(s) and throttle valve(s)
- Equipped with hand pump for manual release of brake
- Inline high pressure filter
- LED's on solenoids
- Test point for readout / bleeding of manifold
- Pressure switch either electronic or mechanical type
- Level & temperature switch in tank
- Pressure gauge mounted on test point (minimess) hose inside cabinet
- Stainless steel enclosure mounted on bracket with vibration dampers
- Enclosure door with cam lock with double bit as standard or upgraded with stainless pad-lockable swing handle (optional)
- Removable drip tray to capture spills
- HPU can be mounted on slides for easy maintenance (optional)
- Sun roof / dirt cover 30° (optional)






### HYDRAULIC DIAGRAM


The schematics illustrates the difference between basic (single return) & premium (double return). The additional circuit on the premium version is marked with red in the below image. The motor pressure switch can either be mechanical type (2 switches) or electronic type (IFM) (1 switch) – here shown as electronic type.

### **Basic Version: Single Dump / Single Return Line**



### Premium Version: Double Dump / Dual Return Line


Red area indicates additional circuit for redundant return/dump




### **ELECTRICAL DIAGRAM / SCHEMATIC**

The electrical components on the hydraulic power unit – excluding the motor - are prewired to the junction box. The motor supply wire and motor starter is not part of the unit and must be provided locally. The connection from installation to junction box and motor is to be made through the removable brass entry plate in the left hand side and must be made during installation. It is not normal to connect the brake indicators though the junction box on the unit. The electrical diagram / schematic vary according to the selections made (basic / premium / mechanical or electronic pressure switch) – below two typical schematics

### Premium Version (Redundant Valves) with IFM Pressure Switch:



### Premium Version (Redundant Valves) with Mechanical Pressure Switch:




Valves / Coil	Directional poppet valve 2/2 & coil 21W (1x or 2x) - Hydac			
Pressure switch	Electronic sensor (1x) – IFM 7001 Mechanical pressure switch (2x) - Bosch Rexroth HED5			
Level & temperature switch	Level indicator with temperature switch 70°C - Lund & Sorensen			
Motor	IEC common motor 0,75kW for 50Hz / 0,90kW for 60Hz			
Terminals (in JB)	Screw terminals - Wago	Screw terminals - Wago		
	IEC Power circuit wiring colors			
Wire colors	Protective earth (PE) Neutral (N) Line, single phase (L) Line, 3 phase (L1) Line, 3 phase (L2) Line, 3 phase (L3)	Green-yellow Blue Brown Brown Black Grey		

### Component List (Quantities depend on configuration)


### **Recommended Brake Limits for 2 Stage Pressures**

Choosing brake torques and brake sizes that result in a hydraulic two stage pressure lower than 10bar (lower limit) is not recommended as the counter pressure valve is very difficult to set at this low pressure. The brake pressure curves indicate the two stage pressure at the corresponding torque. If pressure is below the 'lower limit' the combination is not recommended.


#### **BSFI 200 Series:**



#### **BSFI 3000 Series:**




#### **BSFI 300 Series:**






### SELECTION SHEET – 2 STAGE HYDRAULIC POWER UNIT

Dimensions (600x800x400mm) (WxHxD)





### **HPU Selection Sheet**

Version (select one)			Accesories (select one)
Premium (dual return)			Unit mounted on slides (default)
Basic (single return)			Unit fixed on bracket
Motor (AC 50 Hz/60Hz)	(Selec	t one)	Door mounting (select one)
TENC = Non Ventilated	TENV	TEFC	Left side mounted (default)
1x230V 50 Hz / 1x230V 60 Hz	_		Right side mounted
3x400V 50 Hz / 3x480V 60 Hz			Cabinet accesories
3x500V 50 Hz / 3x575V 60 Hz	-		Cam lock with double bit (default)
3x690V 50 Hz / 6x690V 60 Hz	-		Pad-Lockable swing handle
Coil voltage (select one)	AC	DC	Flat cabinet (no sun roof)(default)
12 VDC	_		Dust cover / sun roof 30°
24 VDC	_		Pressure connection entry (select one)
48 VAC / VDC			Left side mounted (default)
110 VAC		-	Right side mounted
230 VAC		-	Bottom (left) mounted
Pressure switch (select one)			Pressure connection type (select one)
Electrical (IFM) (Port P1)			JIC connection (default)
Mechanical (Port 40 & 42)			Ermeto connection (10L)
Hydraulic / brake parameters	s:		
Brake series / size:			
Type of brake (Mono / Dual)			
Number of brakes:			pcs
Braking torque $M_T$ % (30-70%):(% of 100% torque)			%
Braking time ∆t (5-25sec): (2-stage	e time)		Sec
Standard (if no values given): M	<sub>T</sub> % =50% &	∆t =10 s	ес
Customer Name / Project:			
Other Information:			
Name & Date:			

### **Technical Specifications**

Motor standard IEC – TEFC (fan cooled) IEC – TENV (non ventilated)

#### Available motor voltages

AC 50Hz / 60 Hz 1 x 230V 3 x 400V / 480V 3 x 500V / 575V 3 x 690V / 690V

All AC motors have voltage tolerance ± 10% Power consumption: 0.75kW (50Hz) 0.90KW (60Hz)

#### **Available Coil Voltages**

DC: 12V, 24V, 48V, 110V AC: 110V, 230V

Power consumption: 19W (one coil)

**Oil Tank Size** 6 liter / 1.58 gallon (US) / 1.32 gallon (imperial)

Hand Pump Inclusive

Pressure Switch Electronic or Mechanical

Cabinet / Enclosure Stainless steel (1.4305 / AISI 304) incl. junction box

Protection class IP66 Protection class for electrical components IP55

Internal wiring according to IEC EN 60204-1

Mounted on suspension bracket with dampers and lifting point. Drip tray to take spills. Slides for easy maintenance (optional).

#### **Ambient Temperature Limits**

-20°C to +50°C / -4°F to +122°F The hydraulic fluid must match temperature level

#### Altitude

Below 1000 MASL

#### Weight

Approx.: 100kg / 220lb (without oil)

# **F SVENDBORG BRAKES**

**Regal Rexnord** 

svendborg-brakes.com

+45 63 255 255

regalrexnord.com

The proper selection and application of products and components, including assuring that the product is safe for its intended use, are the responsibility of the customer. To view our Application Considerations, please visit <a href="https://www.regalrexnord.com/Application-Considerations">https://www.regalrexnord.com/Application-Considerations</a>.

To view our Standard Terms and Conditions of Sale, please visit https://www.regalrexnord.com/Terms-and-Conditions-of-Sale.

"Regal Rexnord" is not indicative of legal entity. Refer to product purchase documentation for the applicable legal entity. Regal Rexnord and Svendborg Brakes are trademarks of Regal Rexnord Corporation or one of its affiliated companies. © 2020, 2024 Regal Rexnord Corporation, All Rights Reserved. MCB-P-7902-SV-EN-US 9/24

# fr**FRegal**Rexnord®